
















Machine	Explode	Code	Description
GL347 Buffalo Manual Fill Water Boiler 20Ltr	1		Lid Handle
GL347 Buffalo Manual Fill Water Boiler 20Ltr	2		S/S Lid
GL347 Buffalo Manual Fill Water Boiler 20Ltr	3		Body Handle
GL347 Buffalo Manual Fill Water Boiler 20Ltr	4		S/S Reservoir
GL347 Buffalo Manual Fill Water Boiler 20Ltr	5	AF336	Tap
GL347 Buffalo Manual Fill Water Boiler 20Ltr	6		140C Thermostat
GL347 Buffalo Manual Fill Water Boiler 20Ltr			Manual-Reset Assembly
GL347 Buffalo Manual Fill Water Boiler 20Ltr	7		Steel Support Bracket
GL347 Buffalo Manual Fill Water Boiler 20Ltr	8		S/S Base
GL347 Buffalo Manual Fill Water Boiler 20Ltr	9		Bottom Cover
GL347 Buffalo Manual Fill Water Boiler 20Ltr	10		Plastic Foot
GL347 Buffalo Manual Fill Water Boiler 20Ltr	11		105 Thermostat
GL347 Buffalo Manual Fill Water Boiler 20Ltr	12	AK110	Temperature Dial
GL347 Buffalo Manual Fill Water Boiler 20Ltr	13		Red Control Light
GL347 Buffalo Manual Fill Water Boiler 20Ltr			Green Control Light
GL347 Buffalo Manual Fill Water Boiler 20Ltr	14		Power Cord & Plug
GL347 Buffalo Manual Fill Water Boiler 20Ltr	15		Power Cord Clip