







































Machine	Explode	Code	Description
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	1		Jar Lid Cover
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	2		Jar Lid
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	3	DM876	Jar ONLY (64 oz. stackable Raptor)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	4		Blade Assembly
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	5		Bearing Holder O Ring
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	6		Nut Gasket
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	7		Bearing Holder Nut
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	8	AC930	Drive Clutch
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	9		Jar Pad
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	10		Motor
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	11		Dampening Plate Gasket
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	12		MX Housings, Ferrite Core & Cord
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	12		Black Top Housing (older units)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	13		Motor Foam (2 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	14		Dampening Plate Bushing (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	15		Dampening Plate Sleeve (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	16		Washer (2 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	17		Screw (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	18		Soft Start Control Panel (XPrep)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	18		Soft Start Control Panel (Xtreme)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	19		Housing Foam Rear Baffle
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	20		Housing Foam Front Baffle
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	21		MX Housings, Ferrite Core & Cord
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	21		Motor Housing (older units)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	22		Washer (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	23		Bottom Housing Foam Baffle
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	24		Foam Baffle
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	25		MX Housings, Ferrite Core & Cord
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	25	AC934	Cord Set (older units)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	26		Strain Relief
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	27		Cable Tie (3 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	28		MX Housings, Ferrite Core & Cord
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	28		Black Bottom Housing (older units)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	29		Screw (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	30		Corner Post (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	31		Screw (4 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	033484	033484	Brush/ Spring (2 required)
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	032322		2 Piece lid
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	030889	AE166	Blending Ass'y Kit
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	503351		MX Coupling Wrench
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	032761		MX Jar Wrench
Waring X-Prep Kitchen Blender - 1.8Ltr Jar	Not shown	AC900	Waring 48oz Stacking MX Jar with lid



Wiring Diagram



Wiring Diagram

(older units)